

INSTALLATION GUIDE

A Replace existing cam lock with KitLock

- | | | | |
|--------|--|---------|--|
| Step 1 | Remove existing cam lock. | Step 8 | Tighten the lower fixing nut and upper bolt. |
| Step 2 | Place the 16mm (5/8") template hole over the hole left by the cam lock and mark the upper fixing hole. | Step 9 | Select the cam which suits your door and frame and attach it to the square shaft at the end of the spindle. |
| Step 3 | Drill the 6mm (1/4") fixing hole. | Step 10 | Now check the operation of the lock using the factory User Code 22 44. |
| Step 4 | Fit the KitLock to the door by passing the spindle through the 16mm (5/8") hole. | Step 11 | If the lock is functioning correctly, CHANGE THE DEFAULT MASTER CODE 11 33 55 77 and DEFAULT USER CODE 22 44 and program the lock using the programming and operating instructions enclosed. |
| Step 5 | If required, from the inside of the door, pass either of the packing pieces over the spindle to centralise the lock. | | |
| Step 6 | Now secure the lock by threading the large nut onto the spindle. | | |
| Step 7 | Fit one of the upper fixing bolts to suit your door thickness. | | |

B New Installation

- | | | | |
|--------|--|--------|---|
| Step 1 | Place template on door and mark upper 6mm (1/4") hole and lower 16mm (5/8") hole. IMPORTANT NOTE: Before drilling fixing holes, please ensure the position of the KitLock when fitted will allow enough clearance for selected cam to work. | Step 2 | Drill both fixing holes. |
| | | Step 3 | Continue installation from step 4 to 11, above. |

II-KL1000-v2:0813

CODELOCKS LTD UK

Tel: +44 (0) 1635 239645
Fax: +44 (0) 1635 239644
sales@codelocks.co.uk

Helpline, service & spares
FREEPHONE 0800 393405

CODELOCKS INC US

Tel: +1 714 979 2900
Fax: +1 714 979 2902
sales@codelocks.us

KitLock is a
Codelocks Ltd Brand
www.kitlock.com



WWW.KITLOCK.COM

KL1000

Vertical


Installation Instructions

KitLock
Coded Locker Solutions

Please read carefully:

- Before installing the lock, load the batteries and familiarise yourself with the operation and programming.
- The handle will not turn until you enter the factory default Master Code 11 33 55 77 or the User Code 22 44.
- Please see programming guide to set your own codes.
- Your KitLock is supplied ready to fit to doors up to 19mm ($\frac{3}{4}$ " thick. For doors between 19mm ($\frac{3}{4}$ " and 25mm (1") thick, you will need to install the 28.5mm ($1\frac{1}{8}$ " spare spindle (see below). A 12mm ($\frac{1}{2}$ " spindle is also included for sheet metal doors (see below).

1. Remove the lower 2 fixing screws.
2. Remove cover plate, spindle and threaded shaft.
3. Replace with spare spindle and threaded shaft.
4. Replace cover plate.


**The KitLock can be fitted to:**

A Cabinets, cupboards and lockers etc as a direct replacement for existing cam locks.

B It can also be fitted easily to cupboards and cabinets that do not have an existing locking device.

- 1 KitLock
- 2 Upper fixing bolt x 2
- 3 Packer pieces x 3
- 4 Locking nut
- 5 Cams x 2
- 6 Cam fixing bolt

Batteries – 2 x 1.5V AAA
Template x 1



Please see installation guide on reverse

Kit·Lock
Coded Locker Solutions